

# MCX-800AD Remote control battery replacement



Use a pin to insert into the hole and push out the front panel PCB and remove it (be careful to avoid damaging the IR LED)



Please use CR2025 or CR2032 batteries